

**Correct as at 8th June 2026. It may be superseded at any time.**

**Extract taken from:** Light vehicle repair certification > Introduction > Inspection and certification process > Vehicle quarantine

## **3-9 Vehicle quarantine**

A repair certifier may operate a quarantine system for vehicles which they are undertaking the repair certification of. The quarantine period can be up to a maximum of 180 calendar days or 100km, whichever is the lesser, and will start from the entry certifier's first inspection date and mileage as recorded on the check sheet.

The repair certifier must meet the following requirements in order to quarantine a vehicle:

- The vehicle must not be driven or removed from the nominated quarantine site unless for the purposes of repair certification. The maximum distance allowable while in quarantine is **100km** from the mileage recorded on the check sheet. If this mileage distance is exceeded the vehicle must be referred to the KSDP for full entry level inspection.
- Details relating to any vehicle that is quarantined must be recorded on LANDATA by the repair certifier in the vehicle notes screen **including mileage, the dates when the vehicle entered quarantine, and the location of the quarantine.**
- The vehicle must be placed into repair certification quarantine within the 21 working days recheck period from the date recorded on the check sheet.

If these requirements are not followed – the vehicle is deemed to have not entered quarantine.

Page amended **21 August 2024** (see [amendment details](#)).