

Correct as at 4th June 2026. It may be superseded at any time.

Extract taken from: In-service certification (WoF and CoF) > Light PSVs > Miscellaneous items > Fuel system

13-2 Fuel system

Reasons for rejection

Mandatory equipment

1. Fuel for a PSV is carried in a temporary fuel tank.

Condition and performance

2. Refer to [general vehicle pages](#).
3. A fuel tank or fuel line shows signs of corrosion.
4. The fuel-tank filling inlet cannot be accessed from outside the body.
5. A fuel cap:
 - a) does not tighten properly, or
 - b) seal is in poor condition.

Summary of legislation

Applicable legislation

- [Land Transport Rule: Passenger Service Vehicles 1999](#).

Mandatory equipment

1. Fuels for a PSV and the vehicle's equipment must be carried in permanent fuel tanks.
2. Each filling inlet must be provided with a leak-proof cap.

Condition and performance

3. Refer to [general vehicle pages](#).
4. Fuel tanks and fuel lines must be:
 - a) corrosion resistant, and
 - b) designed and constructed of durable, fuel-resistant material, and
 - c) securely mounted, and
 - d) reasonably protected from collision damage.
5. Access to the fuel-tank filling inlet must be from outside the body of the PSV.